



More info at:
WWW.TRAKRACER.COM




or follow us at:



@TRAKRACER

TR80-KBMMS - MANUAL VERSION 1A



MS-FS-SIN7


Assembly Guide




IMPORTANT: Different regions may have different models. Please ensure the part numbers on the following pages match those on your product packaging.

MS-FS-SIN7 PARTLIST


ACCESSORIES (NOTE: Extra hardware may be included as spare parts)




Aluminum Profile
TR-8040-800 X1




Aluminum Profile
TR-8040-600 X6




Aluminum Profile
TR-8040-350 X2




Vesa Extension (Right)
TV-EX-R X2




Vesa Extension (left)
TV-EX-R X2




Vesa Mount
TV-VM X1




Reinforced Support Plate (Right)
SRP-R X1



Reinforced Support Plate (Left)
SRP-L X1




Connecting Bracket Plate
AP-TV-S X2



Horizontal Mount Connector
SP-02 X2




40x80 End Cap
EC-80 X8




40x40 Corner Bracket
BC-40 X4




40x40 Corner Bracket Cap
BC-40-CAP X4



Connector Plate
SS-01 X2




Rubber Foot
FR-01 X4




Long Connector T-Nut
LN-M8 X8




M8 Lock Washer
WL-M8 X47




M8x16 Washer (Flat)
WF-M8-16 X4




M8x20 Washer (Flat)
WF-M8-20 X47



M6x16 Flat Hex Screw
SF-M6-16 X8




M8x16 Cap Hex Screw
SH-M8-16 X24




M8x20 Cap Hex Screw
SH-M8-20 X27



M6 Flange Nut
NF-M6 X8





M8 Ball Bearing Nut
NS-M8 X35



ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

01




ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

02

A X4	AA X4	AB X8	AC X8	AD X8	AE X2	AF X1
600mm (23.62")	LN-M8	SH-M8-20	WF-M8-20	WL-M8	SS-01	SRP-L/SRP-R




ASSEMBLY INSTRUCTIONS

MS-FS-SIN7


03

A X1	AA X4	AB X4	AC X4	AD X4	AE X4
STEP 2	NS-M8	SH-M8-20	WF-M8-20	WL-M8	BC-40



04



A X1	AA X1	AB X4	AC X4	AD X4	AE X4
STEP 1	STEP 3	SH-M8-20	WF-M8-20	WL-M8	NS-M8





ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

05



06a





NOTE

- For three monitors under 34", the side brackets (350 mm × 2) are not required.
→ Follow Step 6A, then proceed to Step 9.
- For monitors 34" and above, the side brackets (350 mm × 2) are required.
→ Follow Step 6B, then proceed to Step 7.


ASSEMBLY INSTRUCTIONS

MS-FS-SIN7


06b



07



NOTE
For a single monitor, the horizontal mount connector plate (SP-02) is optional. The monitor can be installed with or without this plate. Using the SP-02 plate is recommended, as it provides a cleaner and more stable setup.




ASSEMBLY INSTRUCTIONS

MS-FS-SIN7


08

AX1	AA X1	AB X8	AC X8	AD X8	AE X8
STEP 6	STEP 7	SH-M8-20	WF-M8-20	WL-M8	NS-M8



09

A X4	AA X4	AB X2	AC X16	AD X16
TV-EX-L	TV-EX-R	TV-VM	SF-M6-16	NF-M6




ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

10

AX1	AA X1	AB X3	AC X3	AD X3	AE X3
STEP 8	STEP 9	SH-M8-20	WF-M8-20	WL-M8	NS-M8



ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

11

AX1


STEP 10

AA X8

EC-80

AB X4

BC-40-CAP



ASSEMBLY INSTRUCTIONS

MS-FS-SIN7

11

IMPORTANT: If your monitor screws are under 8mm (M8), you will need to use washers (not supplied)

