



More info at:
WWW.TRAKRACER.COM




or follow us at:



@TRAKRACER

TR80-KBMMS - MANUAL VERSION 1A



MS-CM-SML2



















Assembly Guide



IMPORTANT: Different regions may have different models. Please ensure the part numbers on the following pages match those on your product packaging.


MS-CM-SML2 PART LIST

ACCESSORIES (NOTE: Extra hardware may be included as spare parts)

 Aluminum Profile TR-8040-600 X1	 Aluminum Profile TR-8040-400 X2	 Aluminum Profile TR-8040-300 X2	 Vesa Extension (Right) TV-EX-R X2
 Vesa Extension (left) TV-EX-R X2	 Vesa Mount TV-B-P X1	 40x80 Corner Bracket CB-80 X2	 Monitor Side Bracket CP-3 X2
 40x40 End Cap EC-80 X8	 Corner Bracket BC-40 X8	 Corner Bracket Cap BC-40-CAP X8	 M8 Ball Bearing Nut NS-M8 X34
 M8 Lock Washer WL-M8 X32	 M8x20 Washer (Flat) WF-M8-20 X34	 M6x16 Flat Hex Screw SF-M6-16 X8	 M8x16 Flat Hex Screw SF-M8-16 X4
 M8x16 Cap Hex Screw SH-M8-16 X2	 M8x20 Cap Hex Screw SH-M8-20 X32	 M8 Flange Nut NF-M8 X4	 M6 Flat Nut NL-M6 X8

ASSEMBLY INSTRUCTIONS

MS-CM-SML2



ASSEMBLY INSTRUCTIONS

MS-CM-SML2

03

A X1

STEP 2

AA X1

TV-B-V

AB X2


SH-M8-16

AC X2

WF-M8-20

AD X2

NS-M8



04

A X2

400mm (15.75")

AA X4

SH-M8-20

AB X4

WF-M8-20

AC X4

WL-M8

AD X8

NS-M8

AE X4


BC-40

AF X2

BC-40

AG X4

SF-M8-16



ASSEMBLY INSTRUCTIONS

MS-CM-SML2

05

A X1

STEP 4

AA X2

SP-03

AB X8

SH-M8-16

AC X8

WF-M8-20

AD X8


WL-M8

AE X4

NS-M8

AF X4

NF-M8



06

A X1

STEP 3

AA X1

STEP 5

AB X4

SH-M8-20

AC X4


WF-M8-20

AD X4

WL-M8

AE X4

NS-M8




ASSEMBLY INSTRUCTIONS


MS-CM-SML2

07

A X1	AA X8	AB X8	AC X8	AD X8
STEP-06	SH-M8-20	WF-M8-20	WL-M8	NS-M8



08




05

ASSEMBLY INSTRUCTIONS

MS-CM-SML2

09

A X6	AA X6
EC-40	NS-40-CAP






06

ASSEMBLY INSTRUCTIONS

MS-CM-SML2

10



ASSEMBLY INSTRUCTIONS

MS-CM-SML2

11

