



TR80-NWM5 PART LIST


ACCESSORIES (NOTE: Extra hardware may be included as spare parts)




Steering Wheel Panel
PWS **X4**



M8x16 Cap Hex Screw
SH-M8-16 **X4**



M6x16 Cap Hex Screw
SH-M6-16 **X4**





D12xD6.5xT1 Washer (Flat)
WF-D12*D6.5*T1 **X4**

ASSEMBLY INSTRUCTIONS

TR-NWMA3

01



ASSEMBLY INSTRUCTIONS

TR-NWMA3

01

