




More info at:
WWW.TRAKRACER.COM



or follow us at:



@TRAKRACER

TR80-KBMMS - MANUAL VERSION 1A

TR80-NWNA4-DD

Assembly Guide



IMPORTANT: Different regions may have different models. Please ensure the part numbers on the following pages match those on your product packaging.

01

SYMBOL LEGEND

01

02

PART LISTS

02

03

ASSEMBLY NOTES

TR80-NWNA4-DD03

04

ASSEMBLY INSTRUCTIONS

TR80-NWMA405

TR80-NWMDD205

SYMBOL LEGEND



IMPORTANT: Since there are different versions of each product based on your region, please make sure you are using the correct set of instructions. The part number below should match the one on your box.



IMPORTANT: Due to the nature of cut aluminum profiles, some metal shavings may remain despite our thorough QA cleaning process. We recommend opening boxes and packaging on a hard surface.



NOTE: Some screws and washers may be pre-installed. These are included in the parts list and will need to be loosened and reattached according to the instructions.



Recommended:
Two people for the task



Safety glasses required



Tighten the hardware



Attention/Priority needed



Keep the hardware loose
For adjustments



Reserve for the next step



Make the necessary adjustments



Mirrored components
(same on both sides)




Break the tab off the corner bracket


PART LISTS

COMPONENTS / ACESSORIES

BOX: TR80-NWMA4




Aluminum Profile
TR-12040-180 **x2**




Wheel Mount Outer Plate
WM-TR4-PP **x2**




Wheel Mount Inner Plate
WM-TR4-WP **x2**




Wheel Mount Spacer
WM-TR4-FN **x4**




M6x25 Cap Hex Screw
SH-M6-25 **x4**




M8x25 Cap Hex Screw
SH-M8-25 **x12**




M8x20 Flat Hex Screw
SF-M8-20 **x12**



M8x20 Washer (Flat)
WF-M8-20 **x10**




M8 Washer (Lock)
WL-M8 **x8**




M8 T-Nut
NS-M8 **x8**


BOX: TR80-NWMDD2




M6x20 Cap Hex Screw
SH-M6-20 **x2**




M8x20 Cap Hex Screw
SH-M8-20 **x4**




M8x25 Cap Hex Screw
SH-M8-25 **x4**



M6x16 Washer (Flat)
WF-M6-16 **x2**



M8x20 Washer (Flat)
WF-M8-20 **x4**




Wheel Front Mount
WM-DD2 **x1**


NOTE: Extra hardware may be included as spare parts

ASSEMBLY NOTES


TR80-NWNA4-DD



INSTALLATION ORDER FOR SCREWS & WASHERS




HOW TO MEASURE SCREWS



ASSEMBLY NOTES


TR80-NWNA4-DD

NS-M8 & NS-M6



ASSEMBLY INSTRUCTIONS

TR80-NWNA4-DD



ASSEMBLY INSTRUCTIONS

TR80-NWNA4-DD

03

02

STEP 02

P x2


WM-DD2

Mx4

SH-M8-25

0 x2

WF-M8-20



04

03

STEP 03

F x8

SH-M8-25

H x8


WF-M8-20

I x8

WL-M8

J x8



NS-M8




ASSEMBLY INSTRUCTIONS

TR80-NWNA4-DD


05



06




07



ASSEMBLY INSTRUCTIONS

TR80-NWNA4-DD

06



ASSEMBLY INSTRUCTIONS

TR80-NWNA4-DD