


SIM LAB

INSTRUCTION MANUAL



SIM FLOOR
VERSION 1.0
Last updated: 17-02-2025


BEFORE YOU START:

Thank you for purchasing this Sim-Lab product! On the following pages, you will find detailed instructions on assembly. This requires only a set of simple tools and some of your time. Please check the bill of materials before starting (page 6) and make sure all the parts are delivered.

This manual uses a P1X Pro to show how to install it, GT1 Pro and GT1-EVO/P1X users can follow along.

Inserting Slot-Nuts:


You got excited, finished the build, put the caps on, but forgot to install one element. Do not worry. It happens to everyone. In this diagram, you can see how to insert a Slot-Nut directly into the slot from the side. You can also use one of your smaller Hex wrenches to help wiggle the Slot-Nut in place.




Breaking tabs:

Sometimes tabs from corner brackets need to be broken off in order to fit as instructed. Place a flathead screwdriver behind the tab and tilt upwards.

Always make sure to point away from you while doing so. To know when to do this, we will show the following symbol  next to the brackets.



Tools needed:



6MM




13MM




—

Slot-Nut M8






4X



Corner
Bracket

M8 X 16

Washer M8





4X

4X


4X

Break all tabs off of the
corner brackets.





Corner bracket caps
are optional here.



BOX A - Sim Shelf Universal HARDWARE KIT

#	Part	QTY	Note
A1	Sim Floor	1	
A2	Corner bracket 40x40	4	
A3	Corner bracket 40x40 Cap	4	
A4	Bolt M8 X 16 DIN 912	4	
A5	Bolt M8 X 20 DIN 912	4	
A6	Washer M8 DIN 125-A	8	
A7	Slot-Nut M8	4	
A8	Lock-Nut M8	4	

Disclaimer: for some entries on this page, we may supply more than required as spare materials. Don't worry if you have some leftovers, this is intentional.

If you still have some questions regarding assembly of this product or about the manual itself, please refer to our support department. They can be reached at

support@sim-lab.eu

Alternatively, we now have a Discord server where there are quite some experienced Sim-Lab customers hanging out. They might just help you along if you ask them nicely ;)

www.sim-lab.eu/discord

If you feel like printing this manual, please consider the environment before doing so. For the best results, make sure you print at 100% scale without borders.

[Product page on the Sim-Lab website:](#)

