


SIM LAB

INSTRUCTION MANUAL



SIM SHELF UNIVERSAL

VERSION 1.0

Last updated: 23-07-2024

BEFORE YOU START:


Thank you for purchasing this Sim-Lab product! On the following pages, you will find detailed instructions on assembly. This requires only a set of simple tools and some of your time. Please check the bill of materials before starting (page 6) and make sure all the parts are delivered.

For this V2 version of our Sim Shelf, we made sure it can be fitted on both current and previous generation cockpits. This manual uses a P1X Pro to show how to install it, GT1 Pro and GT1-EVO users can follow along. The inner holes on the shelf will line up with the slots in the brackets, making up for the difference in width between the cockpits.


Another change in comparison to the previous shelf, is that we now provided slots to help you in fixing your power strips in place.

Inserting Slot-Nuts:

You got excited, finished the build, put the caps on, but forgot to install one element. Do not worry. It happens to everyone. In this diagram, you can see how to insert a Slot-Nut directly into the slot from the side. You can also use one of your smaller Hex wrenches to help wiggle the Slot-Nut in place.




Tools needed:




4/6MM




10MM



Slot-Nut M8




4X




Please double check and make sure all bolts are tight before placing your PC on the shelf.

Bracket Left
(A2)




1X

Bracket Right
(A3)




1X

Cap-Washer
M8




4X

M8 X 20






4X

Washer M8
(DIN 988)





4X





Please double check and make sure all bolts are tight before placing your PC on the shelf.



BOX A - Sim Shelf Universal HARDWARE KIT

#	Part	QTY	Note
A1	Sim Shelf Universal	1	
A2	Bracket Left	1	
A3	Bracket Right	1	
A4	Bolt M8 X 20 DIN 912	4	
A5	Bolt M6 X 20 DIN 7991	4	
A6	Cap-Washer M8	4	Black.
A7	Washer M8 DIN 988	4	
A8	Washer M6 DIN 125-A	4	
A9	Slot-Nut M8	4	
A10	Lock-Nut M6	4	

Disclaimer: for some entries on this page, we may supply more than required as spare materials. Don't worry if you have some leftovers, this is intentional.

If you still have some questions regarding assembly of this product or about the manual itself, please refer to our support department. They can be reached at

support@sim-lab.eu

Alternatively, we now have a Discord server where there are quite some experienced Sim-Lab customers hanging out. They might just help you along if you ask them nicely ;)

www.sim-lab.eu/discord

If you feel like printing this manual, please consider the environment before doing so. For the best results, make sure you print at 100% scale without borders.

[Product page on the Sim-Lab website:](#)

